



### LIFTING CRANE SG35

The SG35 davit is a lifting device made entirely of high-strength steel that makes it light and at the same time robust, designed with a capacity of 35kg for lifting wheelchairs.

The SG35 davit has a 3-point articulated loading arm that allows the wheelchair to be easily positioned inside the vehicle between the front and rear seats. The lifting movement is electric by means of a push-button panel integrated in the arm.

The SG35 davit is equipped with an additional cable to manage, as an alternative to the original push-button panel, the ascent and descent of the rope through an auxiliary control, easy to reach for the user. The crane allows folding folded wheelchairs to be lifted.

#### GENERAL CHARACTERISTICS

MAXIMUM LOAD	35 Kg
POWER SUPPLY	12 V
ARM EXTENSION	962 mm
ROTATION ANGLE	180°
RECLINING ARM	430 mm