



## SG50 LIFTING CRANE

The SG50 crane is a lifting device suitable for facilitating the insertion of wheelchairs in the rear compartment of the vehicle.

It is made of special high-strength steels: this allows for a light and handy device with high performance, in fact, in addition to wheelchairs it is able to lift mini-scooters up to 50 Kg.

SG50 has a push-button panel for integrated ascent / descent and is provided with an additional cable to manage, alternatively, the ascent and descent of the rope through an auxiliary control, easy to reach for the user. A series of belt or rocker arm attachments are also available on request to facilitate the wheelchair coupling system.

The crane allows you to lift folded wheelchairs closed and, using the special sling, each type of wheelchair. After use it can be laid in the trunk to reduce the space required.

### GENERAL CHARACTERISTICS

MAXIMUM LOAD	50 Kg
POWER SUPPLY	12 V
MAXIMUM HEIGHT	1090 mm
ARM EXTENSION	875 mm
ROTATION ANGLE	180°
MINIMUM HEIGHT	690 mm
MINIMUM OPENING	640 mm